ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT / STOP	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DTV / VCR	/ SOURCE
TIMER	
SUBTITLE	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+ / PREV	P+
CH - / NEXT	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAVORITE	FAV
PAUSE	

ORIGINAL	SUPERIOR
RED / ALBUM	RED
GREEN / MUSIC	GREEN
YELLOW / MOVIE	YELLOW
BLUE / MULTISCN	BLUE
AUDIO	SHIFT+MUTE