ORIGINAL	SUPERIOR
DVD POWER	POWER
A / AUDIO	MUTE
TOP MENU / DIR. NAV.	MENU
CANCEL / *	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT SELECT	/ SOURCE
VIDEO PLUS+	
FUNCTIONS	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT / STEP BACK	LEFT
RIGHT / STEP FWD	RIGHT
ENTER	OK
RETURN	BACK
/ TIMER	SLEEP
DIRECT TV REC.	TV/DTV
INFO	INFO
PROG. / CHECK	EPG
REC. MODE	FAV
PAUSE	
STOP	/ SMART
REC	RED

ORIGINAL	SUPERIOR
SLOW/SEARCH REW	GREEN
PLAY / x1.3	YELLOW
SLOW/SEARCH FWD	BLUE
SUB. MENU	SHIFT+MENU
C / ERASE	SHIFT+EXIT
CH+	SHIFT+ P+
CH -	SHIFT+ P -
MANUAL SKIP	SHIFT+RIGHT
TIME SLIP	SHIFT+SLEEP
STATUS	SHIFT+INFO
F. REC.	SHIFT+FAV
EXT. LINK	SHIFT+RED
B / CREATE CHAPTER	SHIFT+YELLOW