ORIGINAL	SUPERIOR
POWER	POWER
TOP PANEL OPEN	1
TOP PANEL CLOSE	2
BAND	-/--
DISPLAY	▭
C – RESET	⊕
DECK 1 – 2	⊟
VOLUME+	VOL+
VOLUME -	VOL -
CD SKIP NEXT	P+
CD SKIP PREV	P -
REPEAT	BACK
SLEEP	SLEEP
RANDOM	TV/DTV
REV MODE	EPG
S. VIRTUALIZER	FAV
CD STOP	■ / SMART
CD PLAY/PAUSE	YELLOW
TAPE STOP	SHIFT+ ■
TAPE REW	SHIFT+GREEN
TAPE PLAY	SHIFT+YELLOW
TAPE FF	SHIFT+BLUE

ORIGINAL	SUPERIOR