ORIGINAL	SUPERIOR
POWER	POWER
MUTING	MUTE
MENU	MENU
TOP MENU	EXIT
DVD	1
L1/OPT.	2
LINE	3
TUNER	4
DISPLAY	
PRO LOGIC	
FUNCTIONS	
EQ.	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
MULTI – REAR	TV/DTV
STATUS	INFO
SEAT POS.	FAV

ORIGINAL	SUPERIOR
EJECT	/ NET TV
PAUSE	
STOP	/ SMART
REC	RED
SLOW/SEARCH REW	GREEN
PLAY / x1.3	YELLOW
SLOW/SEARCH FWD	BLUE