ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
TOP MENU/DIRECT NAVIG	MENU
CANCEL/RESET	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT SELECT	/ SOURCE
FUNCTIONS	-/--
DISPLAY	
STATUS	
SUB – MENU	
SHOW VIEW	
TRK/V-LOCK/CH+	VOL+
TRK/V-LOCK/CH -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
TIME SLIP	SLEEP
DIRECT TV REC	TV/DTV
EXT LINK	INFO

ORIGINAL	SUPERIOR
PROG/CHECK	EPG
REC MODE	FAV
PAUSE	⏸
STOP	■ / SMART
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
TIMER	SHIFT+POWER
VHS	SHIFT+1
DVD	SHIFT+2
DUBBING VHS/A	SHIFT+
DUBBING/DVD/B	SHIFT+
DVD ERASE/C	SHIFT+
CREATE CHAPTER	SHIFT+