| ORIGINAL | SUPERIOR |
|---|---|
| ⏻ | POWER |
| 🔇 | MUTE |
| MENU | MENU |
| CANCEL | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| FL. SELECT | / SOURCE |
| >10 | -/-- |
| DISPLAY | |
| POSITION MEMORY | |
| SETUP | |
| SUBTITLE | |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| UP | UP |
| DOWN | DOWN |
| LEFT | LEFT |
| RIGHT | RIGHT |
| ENTER | OK |
| RETURN | BACK |
| SLEEP | SLEEP |
| RANDOM | TV/DTV |
| SEQUENTIAL | INFO |
| PROGRAM | EPG |
| TOP MENU | FAV |

| ORIGINAL | SUPERIOR |
|---|---|
| OPEN/CLOSE | / NET TV |
| PAUSE | |
| STOP | / SMART |
| REW | GREEN |
| PLAY | YELLOW |
| FWD | BLUE |
| A.SDR | SHIFT+ |
| ANGLE | SHIFT+ |
| BASS | SHIFT+ |
| CINEMA | SHIFT+ |
| REPEAT | SHIFT+BACK |
| D.EHN | SHIFT+SLEEP |
| DISC | SHIFT+TV/DTV |
| QUICK REPLAY | SHIFT+EPG |
| REPEAT A – B | SHIFT+FAV |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |