ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
INTRO	MENU
DEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
>10	-/--
DISPLAY	▭
BASS	⊕
TREBLE	⊖
SURROUND	▤
VOL+	VOL+
VOL -	VOL -
FF / SKIP NEXT	P+
REW / SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
SLEEP	SLEEP
TUNER/BAND	TV/DTV
DIMMER	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
MARKER	FAV
STOP	■ / SMART
REC/PLAY	RED
CD PLAY/PAUSE	YELLOW
CLOCK/TIMER	SHIFT+POWER
AUTO OFF	SHIFT+EXIT
< ALBUM	SHIFT+LEFT
ALBUM >	SHIFT+RIGHT
TITLE SEARCH	SHIFT+INFO
PRESET EQ	SHIFT+EPG
PLAY MODE	SHIFT+FAV
TAPE PLAY	SHIFT+YELLOW