ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
AUTO OFF	MENU
DEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AUX	/ SOURCE
>10	-/--
CLOCK/TIMER	
D.BASS	
INPUT LEVEL	
PRESET EQ	
VOL+	VOL+
VOL -	VOL -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
SLEEP	SLEEP
RADIO	TV/DTV
DIMMER	INFO
PROGRAM	EPG
RE – MASTER	FAV

ORIGINAL	SUPERIOR
CD EJECT	/ NET TV
/ PLAY	
STOP	/ SMART
REW / SKIP PREV	GREEN
CD PLAY/PAUSE	YELLOW
FWD / SKIP NEXT	BLUE
SURROUND	SHIFT+MUTE
IPOD MENU	SHIFT+MENU
TUNE MDOE	SHIFT+EXIT
PLAY MODE	SHIFT+FAV
IPOD EJECT	SHIFT+
IPOD PLAY/PAUSE	SHIFT+YELLOW