ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
PLAY MENU	MENU
AUTO OFF	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
CLOCK/TIMER	/ SOURCE
> = 10	-/--
DISPLAY – DIMMER	
/ PLAY	
D. BASS	
IPOD MENU	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
DEL	BACK
SLEEP	SLEEP
PRESET EQ	TV/DTV
RADIO MENU	INFO

ORIGINAL	SUPERIOR
PROGRAM	EPG
SOUND	FAV
STOP	/ SMART VIDEO
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
CD	SHIFT+1
EXT – IN/RADIO	SHIFT+2
IPOD	SHIFT+3