| ORIGINAL | SUPERIOR |
|---|---|
| VTR | POWER |
| AUDIO OUT | MUTE |
| CLOCK / COUNTER | MENU |
| TIME SEARCH | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| INPUT SELECT | / AV |
| -/-- | -/-- |
| MONITOR | |
| AV LINK | |
| RESET | |
| ZERO STOP | |
| SKIP NEXT | P+ |
| SKIP PREV. | P- |
| TRACKING / V-LOW+ | UP |
| TRACKING / V-LOW- | DOWN |
| SEARCH- | LEFT |
| SEARCH+ | RIGHT |
| SEARCH | OK |
| REPEAT | BACK |
| TIME REC | SLEEP |
| PAL / MESECAM | TV/DTV |
| TAPE REMAIN | EPG |
| STILL ADV | FAV |
| PAUSE / STILL | |

| ORIGINAL | SUPERIOR |
|---|---|
| STOP | |
| REEC | RED |
| REW | GREEN |
| PLAY | YELLOW |
| FWD | BLUE |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |