ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
TIMER	MENU
TIMER ON/OFF	EXIT
CD DIRECT 1	1
CD DIRECT 2	2
CD DIRECT 3	3
AUX/CDR	/ SOURCE
AUTO REV.	-/--
DIM	
CD 123	
TUNER	
TAPE	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
BASS+	UP
BASS -	DOWN
TREBLE -	LEFT
TREBLE+	RIGHT
CLOCK	OK
REPEAT	BACK
SLEEP	SLEEP
SHUFFLE	TV/DTV

ORIGINAL	SUPERIOR
NEW	INFO
PROGRAM	EPG
IS	FAV
STOP	/ SMART
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE