ORIGINAL	SUPERIOR
DVD	
POWER	POWER
AUDIO	MUTE
SYSTEM MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD	/ SOURCE
LIST/DISC MENU	-/--
DISPLAY	
ZOOM	
SHOWV. / VIDEOPL.+	
D. DUBBING	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
TIMER	SLEEP
REC. MODE	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
CHAPTER	EPG
THUMBNAIL	FAV
OPEN / CLOSE	/ NET TV
PAUSE / STEP	
STOP	/ SMART
RECORD	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE
REPEAT	SHIFT+BACK
SEARCH	SHIFT+EPG
MARKER	SHIFT+FAV
VCR	
SYSTEM MENU	SHIFT+MENU
CLEAR	SHIFT+EXIT
1/2/3/4/5	SHIFT+1/2/3/4/5
6/7/8/9/0	SHIFT+6/7/8/9/0
VCR	SHIFT+
DISPLAY	SHIFT+
DOWN	SHIFT+DOWN
UP	SHIFT+UP
LEFT	SHIFT+LEFT
RIGHT	SHIFT+RIGHT
OK	SHIFT+OK

ORIGINAL	SUPERIOR
TV / VIDEO	SHIFT+ TV/D
OPEN / CLOSE	SHIFT+
PAUSE / STEP	SHIFT+
STOP	SHIFT+
REC	SHIFT+REI
REW	SHIFT+GREI
PLAY	SHIFT+YELL
FWD	SHIFT+BLU