ORIGINAL	SUPERIOR
⏻	POWER
AUDIO	MUTE
DISC MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
EDIT	-/--
DISPLAY	
REC MODE	
SETUP	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ BACK	BACK
TIMER	SLEEP
TV/VIDEO	TV/DTV
SHOWVIEW	INFO
TOOLS	EPG
DIRECT/DUBBING	FAV

ORIGINAL	SUPERIOR
STOP	/ SMART
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE
DVD	SHIFT+1
VCR	SHIFT+2
P+	SHIFT+ P+
P -	SHIFT+ P -
REPEAT	SHIFT+BACK
SELECT	SHIFT+FAV