ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
SETUP	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
BASS	/ SOURCE
TREBLE	-/--
ZOOM	
HDMI/ANGLE	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
SOUND MODE	TV/DTV
i / INFO	INFO
REPEAT / PROGRAM	EPG
SURROUND	FAV
OPEN/CLOSE	/ NET TV

ORIGINAL	SUPERIOR
PAUSE	⏸
STOP	■ / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO SYNC.	SHIFT+MUTE
AUDIO SOURCE	SHIFT+1
DISC	SHIFT+2
DOCK for iPod	SHIFT+3
RADIO	SHIFT+4
USB	SHIFT+5