ORIGINAL	SUPERIOR
VCR POWER	POWER
AUDIO	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SPEED	-/--
DISPLAY	
SMART PICTURE	
PROG+	VOL+
PROG -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TIMER	SLEEP
VCR/TV	TV/DTV
EJECT	/ NET TV
PUASE/STILL	/ SMART TUBE
STOP	/ SMART VIDEO
REC	RED
REW	GREEN

ORIGINAL	SUPERIOR
PLAY	YELLOW
FWD	BLUE
TV	
TV POWER	SHIFT+POWER
MUTE	SHIFT+MUTE
TV VOL+	SHIFT+ VOL+
TV VOL -	SHIFT+ VOL -
TV CH+	SHIFT+ P+
TV CH -	SHIFT+ P -