ORIGINAL	SUPERIOR
⏻	POWER
AUX	1
CD	2
TUNER	3
TV	4
VCR	5
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
PAUSE	⏸
STOP	■ / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR