ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
MAX ON/OFF	EXIT
CD 1	1
CD 2	2
CD 3	3
CD 4	4
CD 5	5
CLOCK/TIMER	-/--
DISPLAY	▭
CD	⊕
TUNER	⊟
AUX/GAME	⊟
VOL+	VOL+
VOL -	VOL -
TITTLE NEXT	P+
TITLE PREV	P -
REPEAT	BACK
SLEEP	SLEEP
SHUFFLE	TV/DTV
DIM	INFO
PROGRAM	EPG
TIMER ON/OFF	FAV
PAUSE	⏸
STOP	■ / SMART

ORIGINAL	SUPERIOR
REW	GREEN
PLAY	YELLOW
FWD	BLUE