ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
USB DEL	EXIT
AUX	1
CD	2
TAPE	3
USB	4
SNOOZE	-/--
CLOCK/DISPLAY	
TIMER ON/OFF	
TAPE A/B	
TAPE REC	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
BASS+	UP
BASS -	DOWN
TREBLE -	LEFT
TREBLE+	RIGHT
REPEAT	BACK
SLEEP/TIMER	SLEEP
SHUFFLE	TV/DTV
DIM	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
INC.SURR	FAV
STOP	/ SMART
USB REC	RED
REW	GREEN
PLAY/PAUSE	YELLOW
FWD	BLUE