ORIGINAL	SUPERIOR
AMP	POWER
CD	1
TUNER	2
TAPE	3
VOLUME+	VOL+
VOLUME -	VOL -
CD SKIP NEXT	P+
CD SKIP PREV	P -
STATION+	UP
STATION -	DOWN
DISC SELECT	FAV
CD STOP	■ / SMART
CD PLAY	YELLOW
CD	SHIFT+1
TUNER	SHIFT+2
PHONO	SHIFT+3
TAPE 1	SHIFT+4
TAPE 2	SHIFT+5
LINE	SHIFT+6
DECK I	SHIFT+LEFT
DECK II	SHIFT+RIGHT
TAPE PLAY REVERSE	SHIFT+BACK
TAPE SELECT	SHIFT+FAV
TAPE STOP	SHIFT+ ■
TAPE REW	SHIFT+GREEN

ORIGINAL	SUPERIOR
TAPE PLAY	SHIFT+YELLOW
TAPE FWD	SHIFT+BLUE