ORIGINAL	SUPERIOR
STANDBY/ON	POWER
/ AUDIO	MUTE
HOME MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
HOME MENU GALLERY	-/--
DISPLAY	
PHOTO ZOOM	
/ ANGLE	
/ SUBTITLE	
OUTPUT RESOLUTION+	VOL+
OUTPUT RESOLUTION -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
PLAY MODE	SLEEP
POPUP MENU	TV/DTV
FL DIMMER	INFO
VIDEO ADJUST	EPG

ORIGINAL	SUPERIOR
DISC NAV./TOP MENU	FAV
OPEN/CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
	SHIFT+LEFT
	SHIFT+RIGHT
RED	SHIFT+RED
GREEN	SHIFT+GREEN
YELLOW	SHIFT+YELLOW
BLUE	SHIFT+BLUE