ORIGINAL	REPLACEMENT
⏻	POWER
AUDIO	MUTE
MENU	MENU
C / CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SURROUND	-/--
DISPLAY	▭
V. ADJ. / VID. ADJUST	⊞
ANGLE	▣
SUBTITLE	▤
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
FL / DIMMER	INFO
HOME MENU	EPG
PLAY MODE	FAV
OPEN / CLOSE	⏏
PAUSE	⏸
STOP	■

ORIGINAL	REPLACEMENT
REW / STEP BACK	GREEN
PLAY	YELLOW
FWD / STEP FWD	BLUE