ORIGINAL	SUPERIOR
STANDBY/ON	POWER
MUTE	MUTE
MENU	MENU
CLEAR	EXIT
AUX	1
BT A	2
HOME MEDIA GALLERY	3
IPOD A	4
IPOD B	5
DISP OFF	-/--
DISPLAY	
S. RETREIVER	
BASS	
CLASS	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP

ORIGINAL	SUPERIOR
SHUFFLE	TV/DTV
T. EDIT	INFO
PGM	EPG
HI – LITE	FAV
STOP	/ SMART
PLAY/PAUSE	YELLOW
	SHIFT+POWER
SOUND	SHIFT+MUTE
PLAYLIST >	SHIFT+UP
< PLAYLIST	SHIFT+DOWN
< ALBUM	SHIFT+LEFT
ALBUM >	SHIFT+RIGHT
REPEAT	SHIFT+BACK