ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
OSD	
GOTO	
SETUP	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
SLOW	SLEEP
P/N	TV/DTV
TITLE	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
A – B	FAV
EJECT	/ NET TV
STOP	/ SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
VOCAL	SHIFT+
ZOOM	SHIFT+
ANGLE	SHIFT+