ORIGINAL	SUPERIOR
POWER OFF	POWER
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
-20 db	-/--
MONITOR	▭
VOLUME+	VOL+
VOLUME -	VOL -
SCAN/STATION >	P+
< SCAN/STATION	P -
BASS+	UP
BASS -	DOWN
TREBLE -	LEFT
TREBLE+	RIGHT
ENTER	OK
PRE – OUT	BACK
TONE	TV/DTV
REC = MON	INFO
P – TYPE	EPG
P/NEXT	FAV
PAUSE/TIME	⏸ / SMART TUBE
STOP/EXIT	■ / SMART VIDEO
REW/EVENT	GREEN
PLAY/TEST	YELLOW
FWD/SELECT	BLUE
TUNET TV	SHIFT+1

ORIGINAL	SUPERIOR
TAPE/VCR 1	SHIFT+2
TAPE/VCR 2	SHIFT+3
AUX	SHIFT+4
CD DISC	SHIFT+5
PHONO	SHIFT+6
BALANCE R	SHIFT+ VOL+
BALANCE L	SHIFT+ VOL -
SPEAKERS A	SHIFT+ P+
SPEAKERS B	SHIFT+ P -
◀	SHIFT+LEFT
▶	SHIFT+RIGHT
▼ / ▲	SHIFT+OK