ORIGINAL	SUPERIOR
I/⏻	POWER
MUTE	MUTE
TUNER / BAND	AV
+10 / TUNING MODE	-/--
VOLUME+	VOL+
VOLUME-	VOL-
TAPE – PLAY	OK
SURROUND	FAV
CD/MP3-CD – PAUSE	II
CD/MP3-CD – STOP	■
CD/MP3-CD – SKIP PR.	GREEN
CD/MP3-CD – PLAY	YELLOW
CD/MP3-CD – SKIP NE.	BLUE

ORIGINAL	SUPERIOR