ORIGINAL	SUPERIOR
POWER	POWER
/ MENU	MENU
CANCEL	EXIT
USB	/ SOURCE
DISC MENU	
SKIP NEXT	P+
SKIP PREV	P -
UP/SUBTITLE	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
/ ENTER	OK
/ RETURN	BACK
REPEAT	SLEEP
REPEAT A – B	TV/DTV
INFO	INFO
BOOK MARK	FAV
OPNE/CLOSE	/ NET TV
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR