ORIGINAL	SUPERIOR
⏻|	POWER
AUDIO	MUTE
MENU / TV	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ SOURCE
RESET	-/--
DISPLAY	
SHOW VIEW	
X2	
SURROUND	
CH/TRACK+	P+
CH/TRACK -	P-
OK	OK
REMAIN	BACK
SLOW	SLEEP
INDEX	INFO
PAUSE	
STOP	/ SMART
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR