ORIGINAL	SUPERIOR
TV BOX POWER	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
USB	/ SOURCE
RADIO	-/--
PVR	
STALKER	
M3U.TV	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RECALL	BACK
TIMER	SLEEP
WEB TV	TV/DTV
INFO	INFO
EPG	EPG

ORIGINAL	SUPERIOR
RED/ U TUBE	RED
GREEN/SUB – T	GREEN
YELLOW/FORMAT	YELLOW
BLUE/TTX	BLUE
AUDIO	SHIFT+MUTE
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
STOP	SHIFT+ ■
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE