ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
DVD MENU	MENU
CANCEL	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
DISPLAY	▭
ZOOM	⊕
SETUP	⊟
SUBTITLE	≡
VOL+	VOL+
VOL -	VOL-
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
SLOW	SLEEP
PAL – MUL – NT	TV/DTV
SEARCH	INFO
PROGRAM	EPG

ORIGINAL	SUPERIOR
AUDIO	FAV
EJECT	⏏ / NET TV
PAUSE / STEP	II
STOP	■ / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
A – B	SHIFT+ ⊕
ANGLE	SHIFT+ ⊟