ORIGINAL	SUPERIOR
⏻	POWER
MENU/NO	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FUNCTION	/ SOURCE
DSG	-/--
DSIPLAY	
BASS/TRE	
CLOCK TIMER SELECT	
CLOCK TIMER SET	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
ENTER/YES	OK
REPEAT	BACK
SLEEP	SLEEP
SCROLL	TV/DTV
NAME EDIT/SELECT	INFO
PLAY MODE	FAV
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
REW	GREEN
PLAY	YELLOW

ORIGINAL	SUPERIOR
FWD	BLUE
CD	SHIFT+1
MD	SHIFT+2
TAPE	SHIFT+3
TUNER/BAND	SHIFT+4