ORIGINAL	SUPERIOR
⏻	POWER
AUDIO	MUTE
MENU	MENU
CLEAR	EXIT
SHUFFLE	-/--
SURROUND	▭
ANGLE	▭
SUBTITLE	▭
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
🎧 / RETURN	BACK
TIME/TEXT	SLEEP
TV/VIDEO	TV/DTV
PROGRAM	EPG
SEARCH MODE	FAV
PAUSE	⏸
STOP	■ / SMART
SCAN/SLOW REW	GREEN
PLAY	YELLOW
SCAN/SLOW FWD	BLUE

ORIGINAL	SUPERIOR
TOP MENU	SHIFT+MENU
REPLAY	SHIFT+LEFT
REPEAT	SHIFT+BACK
A – B	SHIFT+SLEEP