ORIGINAL	SUPERIOR
⏻	POWER
AUDIO	MUTE
MENU	MENU
C	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
DISPLAY	▭
ZOOM	⊕
ANGLE	▤
SUBTITLE	▤
SKIP/FRAME NEXT	P+
SKIP/FRAME PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
SELECT	OK
RETURN	BACK
REPEAT	INFO
A – B	EPG
SEARCH MODE	FAV
OPEN/CLOSE	⏏ / NET TV
STOP	■ / SMART VIDEO
SLOW/SEARCH REW	GREEN

ORIGINAL	SUPERIOR
PLAY/PAUSE	YELLOW
SLOW/SEARCH FWD	BLUE