ORIGINAL	SUPERIOR
STANDBY/ON	POWER
MUTING	MUTE
MENU	MENU
CLEAR	EXIT
TIMER	-/--
DISPLAY	
DIMMER	
SHUFFLE	
TIME SET	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
ENTER	OK
REPEAT 1/ALL	BACK
SLEEP	SLEEP
FM MODE	TV/DTV
RDS/INFO	INFO
PROGRAM	EPG
TONE	FAV
STOP	/ SMART
RECORD	RED
PLAY/PAUSE	YELLOW

ORIGINAL	SUPERIOR
AUX 1-2	SHIFT+1
CD	SHIFT+2
IPOD/USB	SHIFT+3
PHONO	SHIFT+4
TUNER	SHIFT+5