ORIGINAL	SUPERIOR
CLEAR	EXIT
SOURCE	/ SOURCE
DISPLAY	
CD FINALIZE/ERASE	
CD SYNC	
REC LEVEL+	UP
REC LEVEL -	DOWN
FOLDER -	LEFT
FOLDER+	RIGHT
REPEAT	BACK
SHUFFLE	TV/DTV
PROGRAM	EPG
CD OPEN/CLOSE	/ NET TV
CD STOP	/ SMART
CD RECORD	RED
CD REW/SKIP PREV	GREEN
CD PLAY/PAUSE	YELLOW
CD FWD/SKIP NEXT	BLUE
TAPE COUNTER RESET	SHIFT+EXIT
TAPE RECORD	SHIFT+ VOL+
TAPE FWD	SHIFT+ P+
TAPE REW	SHIFT+ P -
TAPE PAUSE	SHIFT+UP
TAPE STOP	SHIFT+DOWN
TAPE PLAY REVERSE	SHIFT+LEFT

ORIGINAL	SUPERIOR
TAPE PLAY	SHIFT+RIGHT
USB ERASE	SHIFT+BACK
USB PAUSE	SHIFT+
USB STOP	SHFIT+
USB RECORD	SHIFT+RED
USB REW/SKIP PREV	SHIFT+GREEN
USB PLAY	SHIFT+YELLOW
USB FWD/SKIP NEXT	SHIFT+BLUE