| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| DELETE | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| +10 | -/-- |
| DISPLAY | |
| SINGLE | |
| AUTO SPACE | |
| OUTPUT+ | VOL+ |
| OUTPUT - | VOL - |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| INDEX PREV | LEFT |
| INDEX NEXT | RIGHT |
| CLEAR | OK |
| REPEAT | BACK |
| TIME | SLEEP |
| A – B | TV/DTV |
| CHECK | INFO |
| PROGRAM | EPG |
| FADER | FAV |
| OPEN / CLOSE | / NET TV |
| PAUSE | |
| STOP | / SMART |
| REW | GREEN |

| ORIGINAL | SUPERIOR |
|---|---|
| PLAY | YELLOW |
| FWD | BLUE |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |