ORIGINAL	SUPERIOR
POWER	POWER
REC MUTE	MUTE
MENU	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
+10	-/--
DISPLAY	
PLAY MODE	
SYNC REC	
MONITOR	
SKIP NEXT	P+
SKIP PREV	P -
ENTER	OK
REPEAT	BACK
ERASE	SLEEP
FADER	TV/DTV
FINALIZE	INFO
OPEN/CLOSE	/ NET TV
PAUSE	
STOP	/ SMART
REC	RED
REW	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR