ORIGINAL	SUPERIOR
POWER	POWER
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SETUP	
SUBTITLE	
SLOW+	VOL+
SLOW -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
A – B	TV/DTV
TITLE / PBC	INFO
OPEN / CLOSE	
PAUSE	
STOP	
SCAN REW	GREEN
PLAY	YELLOW
SCAN FWD	BLUE
AUDIO	SHIFT+MUTE

ORIGINAL	SUPERIOR