ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
SFC	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
CD	/ SOURCE
+10	-/--
VCR	
TAPE	
EFFECT	
LEVEL	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
DIMMER	BACK
DIRECT TUNE	SLEEP
TV	TV/DTV
STEREO	INFO

ORIGINAL	SUPERIOR
DOLBY II	EPG
BAND TUNER	FAV
TEST	RED
SKIP PREV	GREEN
SKIP NEXT	BLUE
DVD	SHIFT+
SURROUND TOGGLE	SHIFT+1
ENHANCED SURR	SHIFT+2
MODE	SHIFT+
EFFECT+	SHIFT+UP
EFFECT -	SHIFT+DOWN