ORIGINAL	SUPERIOR
OFF / ON	POWER
MUTING -20dB	MUTE
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
CD – >10	-/--
VOLUME+	VOL+
VOLUME -	VOL -
TURNTABLE – PLAY	RIGHT
TURNTABLE – STOP	OK
DIGI. SPACE – ON/OFF	TV/DTV
CD 10 KEY	INFO
TUNER 10 KEY	EPG
SUPER BASS	FAV
OPEN / CLOSE	▲ / NET TV
CD – PAUSE	⏸
CD – STOP	■ / SMART
CD – SKIP PREV.	GREEN
CD – PLAY	YELLOW
CD – SKIP NEXT	BLUE
EASY PLAY – CD	SHIFT+1
EASY PLAY – TAPE	SHIFT+2
EASY PLAY – TUNER	SHIFT+3
SELEC. – DIGITAL AUX	SHIFT+4
SELECTOR – VCR	SHIFT+5
SELECTOR – VDP	SHIFT+6

ORIGINAL	SUPERIOR
TAPE – PLAY REV.	SHIFT+LEFT
TAPE – DECK 1/2	SHIFT+ TV/DTV
TAPE – PAUSE	SHIFT+ ⏸
TAPE – STOP	SHIFT+ ■
TAPE – REW	SHIFT+GREEN
TAPE – PLAY	SHIFT+YELLOW
TAPE – FWD	SHIFT+BLUE