| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| MUTING | MUTE |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| VOLUME+ | VOL+ |
| VOLUME - | VOL - |
| PRESET NEXT | P+ |
| PRESET PREV | P - |
| AUDIO ⏻ | OK |
| DCC | ⏏ / NET TV |
| AUX | ⏸ / SMART TUBE |
| CD | ■ / SMART VIDEO |
| PHONO | RED |
| TAPE 1 | GREEN |
| TAPE 2 | YELLOW |
| TUNER | BLUE |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| ORIGINAL | SUPERIOR |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |