ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ SOURCE	/ SOURCE
OPT	-/--
SUB	
TXT	
VOL+	VOL+
VOL -	VOL -
PROG+	P+
PROG -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK/LIST	OK
BACK	BACK
DTT/SAT	TV/DTV
INFO	INFO
EPG	EPG
/ FILE	FAV
RED	RED

ORIGINAL	SUPERIOR
GREEN / MARK	GREEN
YELLOW / JUMP	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
/ PIP	SHIFT+1
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE