ORIGINAL	SUPERIOR
⏻	POWER
MENU / i	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	/ SOURCE
AGAIN / SP/LP	-/--
ZOOM/INDEX MARK	
SKIP NEXT/PR+	P+
SKIP PREV/PR -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN/GO BACK	BACK
VCR	TV/DTV
PLAY MODE	FAV
OPEN/CLOSE	/ NET TV
PAUSE	/ SMART TUBE
STOP	/ SMART VIDEO
RECORD	RED
REV	GREEN
PLAY	YELLOW
FWD	BLUE

ORIGINAL	SUPERIOR
PURPLE /	SHIFT+
RED / LOCK /	SHIFT+RED
GREEN / TIMER /	SHIFT+GREEN
YELLOW / INFO	SHIFT+YELLOW
BLUE / TITLE / GUIDE	SHIFT+BLUE