ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SLOW	-/--
RCL	
M – P	
TXT	
VOL/USB GAME+	VOL+
VOL/USB GAME -	VOL -
CH/PAGE+	P+
CH/PAGE -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TV / SAT	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
RED / SAT	RED
GREEN / ZOOM	GREEN

ORIGINAL	SUPERIOR
YELLOW / EPG+	YELLOW
BLUE / TV/RADIO	BLUE
AUDIO	SHIFT+MUTE
SUB.	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE / TIMESHIFT	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
PLAY / REC	SHIFT+RED
FWD	SHIFT+BLUE