ORIGINAL	SUPERIOR
⏻	POWER
🔇	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MEDIA	/ SOURCE
PVR	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TIMER	SLEEP
INFO	INFO
EPG	EPG
RED/TV – RADIO	RED
GREEN/FAV	GREEN
YELLOW/TEXT	YELLOW
BLUE/DISP	BLUE

ORIGINAL	SUPERIOR
AUDIO	SHIFT+MUTE
SUB	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE