ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
MENU	MENU
AUX	1
CD	2
IPOD	3
PHONO	4
TUNER	5
USB	6
TONE/BALANCE -	7
TONE/BALANCE	8
TONE/BALANCE+	9
DSIPALY	▭
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
IPOD MENU SEL.+	UP
IPOD MENU SEL. -	DOWN
TUNING -	LEFT
TUNING+	RIGHT
ENTER	OK
REPEAT	BACK
SLEEP	SLEEP
DIMMER	INFO

ORIGINAL	SUPERIOR
MEMORY	EPG
STOP	■ / SMART
PRESET -	GREEN
PLAY / PAUSE	YELLOW
PRESET+	BLUE