| ORIGINAL | SUPERIOR |
|---|---|
| POWER | POWER |
| MUTE | MUTE |
| SET MENU | MENU |
| 6 CH. INPUT | 1 |
| CD | 2 |
| D-TV / CBL. | 3 |
| DVD | 4 |
| MD / CD-R | 5 |
| TUNER | 6 |
| V-AUX | 7 |
| VCR | 8 |
| LEVEL | -/-- |
| TEST | |
| VOLUME+ | VOL+ |
| VOLUME - | VOL - |
| TUNER – PRESET+ | P+ |
| TUNER – PRESET - | P - |
| UP | UP |
| DOWN | DOWN |
| - | LEFT |
| + | RIGHT |
| SELECT | OK |
| SLEEP | SLEEP |
| STEREO / EFFECT | TV/DTV |
| DOLBY / DST SUR. | EPG |

| ORIGINAL | SUPERIOR |
|---|---|
| ENTERTAINMENT | FAV |
| HALL | / NET TV |
| MATRIX 6.1 | |
| MONO / MOVIE | / SMART |
| MOVIE THEATER – 1 | RED |
| MOVIE THEATER – 2 | GREEN |
| ROCK CONCERT | YELLOW |
| TV SPORTS | BLUE |
| TUNER – A | SHIFT+1 |
| TUNER – B | SHIFT+2 |
| TUNER – C | SHIFT+3 |
| TUNER – D | SHIFT+4 |
| TUNER – E | SHIFT+5 |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |