ORIGINAL	SUPERIOR
⏻	POWER
MUTE	MUTE
MENU	MENU
AM	1
FM	2
CD	3
DOCK	4
LINE 1	5
LINE 2	6
PHONO	7
TAPE	8
SPEAKER A	/ SOURCE
SPEAKER B	-/--
OPTION	
VOLUME+	VOL+
VOLUME -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
/ RETURN / REPEAT	BACK
SLEEP	SLEEP

ORIGINAL	SUPERIOR
INFO	INFO
/ SHUFFLE	EPG
DIMMER	FAV
PAUSE	⏸
PLAY	YELLOW
SCROLL DOWN	SHIFT+DOWN
SCROLL UP	SHIFT+UP
PRESET NEXT	SHIFT+ P+
PRESET PREV	SHIFT+ P -