| ORIGINAL | SUPERIOR |
|---|---|
| STANDBY / ON | POWER |
| MUTE | MUTE |
| MENU | MENU |
| CLEAR | EXIT |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| SOUND | / SOURCE |
| BAND | -/-- |
| DISPLAY | |
| ZOOM | |
| ANGLE | |
| SUBTITLE | |
| VOLUME+ | VOL+ |
| VOLUME - | VOL - |
| SKIP NEXT | P+ |
| SKIP PREV | P - |
| UP / PRESET+ | UP |
| DOWN / PRESET - | DOWN |
| LEFT / A – E - | LEFT |
| RIGHT / A – E+ | RIGHT |
| ENTER | OK |
| RETURN | BACK |
| SLEEP | SLEEP |
| DIMMER | INFO |
| MEMORY | EPG |

| ORIGINAL | SUPERIOR |
|---|---|
| PURE DIRECT | FAV |
| OPEN / CLOSE | / NET TV |
| PAUSE | |
| STOP | / SMART |
| REW | GREEN |
| PLAY | YELLOW |
| FWD | BLUE |
| TIMER | SHIFT+POWER |
| AUDIO | SHIFT+MUTE |
| TOP MENU | SHIFT+MENU |
| AUX / PORTABLE | SHIFT+1 |
| DOCK | SHIFT+2 |
| DVD / USB | SHIFT+3 |
| TUNER | SHIFT+4 |
| ON SCREEN | SHIFT+ |
| SETUP | SHIFT+ |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |