



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
#	 / AV
*	-/--
DISPLAY	
GOTO	
SETUP	
SUBTITLE	
VOL+	VOL+
VOL-	VOL-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
PREVIOUS	BACK
COPY.DEL	SLEEP
DEVICE	TV/DTV
OSD	INFO
NEXT	EPG
ROTATE	FAV

[illegible]