



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
GOTO	
TTX	
UP / CH+	UP
DOWN / CH -	DOWN
LEFT / VOL -	LEFT
RIGHT / VOL+	RIGHT
OK	OK
REPEAT	BACK
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAVOURITE	FAV
RED / PVR	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
SUBTITLE	SHIFT+ 
SKIP NEXT	SHIFT+ P+

[illegible]